

## How to use your Super Extractor Jar



- Figure 1** Align Filter grip to Jar Spout and lock Filter onto the Jar by turning clockwise.
- Figure 2** Put ingredients into Filter. (If you are making fruit cocktail, you can put in different fruits such as apple, pineapple, lemon juice with mint leaves together).
- Figure 3** Place Adaptor and close Lid firmly ensuring that Lid nose is aligned to Jar Spout as shown in the picture. Seat Jar Assembly on Top Cap ensuring that the Jar Base locks fit properly in the grooves of the Top Cap.
- Figure 4** Inch 7 to 10 times till ingredients are shredded.
- Figure 5** Open Lid, remove Adaptor, add required amount of water, (Do not exceed the max. indicated level) replace Adaptor, close Lid and run on Speed 1.
- Figure 6** Second extraction is possible for coconut milk (For tamarind extract, remove seeds before extraction).  
Remove Jar Assembly from Mixie by turning the Jar anti-clockwise and lifting the Jar off the Top Cap. Open Lid nose by twisting it up & Pour juice from the Jar (the pulp stays in the Filter).

## Customer Care Centre

### TAMIL NADU

- Avadi** - Ph:044-26555387. ccavadi@preethi.in
- Kelley's** - Ph:044-25321338, 26420318. ccckellys@preethi.in
- Porur** - Ph:044-24761797. ccporur@preethi.in
- T.Nagar** - Ph:044-24347418, 24363366. ccctnagar@preethi.in
- West Tambaram** - Ph:044-22261510. ccctambaram@preethi.in
- Adayar** - Ph:044-24462099. ccadayar@preethi.in
- Chidambaram** - Ph:04144-223256. ccchidambaram@preethi.in
- Coimbatore** - Ph:0422-2232687. cccoimbatore@preethi.in
- Coimbatore** - Ph:0422-2540687. cccoimbatore2@preethi.in
- Coonoor** - Ph:0423-2236878. ccconoosr@preethi.in
- Dharmapuri** - Ph: 04342-263233. ccchdarmapuri@preethi.in
- Dindugul** - Ph:0451-2423060. ccchindigul@preethi.in
- Erode** - Ph:0424-2221200. ccceerde@preethi.in
- Gobichettypalayam** - Ph:04285-228889. ccgobi@preethi.in
- Hosur** - Ph:04344-649857. ccchosur@preethi.in
- Kancheepuram** - Ph:044-27230492. ccckancheepuram@preethi.in
- Karaikal** - Ph:04368-225818. ccckaraikal@preethi.in
- Karaikudi** - Ph:04565-236376. ccckaraikudi@preethi.in
- Karur** - Ph:04324-241989. ccckarur@preethi.in
- Kumbakonam** - Ph:0435-2425142. ccckumabakonam@preethi.in
- Madurai** - Ph:0452-2347386. ccmadurai@preethi.in
- Mayiladuthurai** - Ph:04364-241202. ccmayavaram@preethi.in
- Nagercoil** - Ph:04652-244505. ccnagarcoil@preethi.in
- Namakkal** - Ph:04286-222592. ccnamakkal@preethi.in
- Puducherry** - Ph:0413-2229599. ccputuducherry@preethi.in
- Pudukottai** - Ph:04322-224195. ccputudukottai@preethi.in
- Ramanathapuram** - Ph:04567-222344. ccramnad@preethi.in
- Salem** - Ph: 0427-2250578. ccsaleam@preethi.in
- Thanjavur** - Ph:04362-273565. ccctanjore@preethi.in
- Theni** - Ph: 04546-253603. ccctheni@preethi.in
- Tirunelveli** - Ph:0462-2321824. ccctirunelveli@preethi.in
- Tiruppur** - Ph:0421-4242341. ccctiruppur@preethi.in
- Tiruvannamalai** - Ph:04175-254900. ccctvannamalai@preethi.in
- Tiruvarur** - Ph:04366-222566. ccctiruvarur@preethi.in
- Trichy** - Ph:0431-2751288. ccctrichy@preethi.in
- Trichy** - Ph:0431-2415181. ccctrichycnt@preethi.in
- Tuticorin** - Ph:0461-2331668. ccctuticorin@preethi.in

## Customer Care Centre

- Udumalpet** - Ph:04252-221477. ccudumalpet@preethi.in
- Vellore** - Ph:0416-22159160. ccvellore@preethi.in
- Villupuram** - Ph:04146-222661. ccvillupuram@preethi.in
- Virudhunagar** - Ph:04562-420624. ccvirudhunagar@preethi.in
- ccchirupathi@preethi.in**
- Vijayawada** - Ph:0866-2431158. ccvijayawada@preethi.in
- Vizag** - Ph:0891-2541915. ccvizag@preethi.in
- Vizianagaram** - Ph:08922-226629. ccvzianagaram@preethi.in
- Warangal** - Ph:0870-2447006. ccwarangal@preethi.in

### KARNATAKA

- Bengaluru** - Ph:080-25440335. ccchennur@preethi.in
- Bangalore 1** - Ph:080-22222583, 22130362. ccjnbl@preethi.in
- Bangalore 2** - Ph:080-23324161. ccmb@preethi.in
- Belgaum** - Ph: 0824-2410434. ccbelgaum@preethi.in
- Bellary** - Ph:08392-2277139. ccbellary@preethi.in
- Goa** - Ph:0832 -2445085. ccgoa@preethi.in
- Hubli** - Ph:0836-2352077. ccchubli@preethi.in
- Mangalore** - Ph: 0824-2445085. ccmmangalore@preethi.in
- Mysore** - Ph:0821-2443966. ccmysore@preethi.in
- Shimoga** - Ph: 08182-229759. ccshimoga@preethi.in

### ANDHRA PRADESH

- Eluru** - Ph:08812-221841. cccluru@preethi.in
- Guntur** - Ph:0863-2214551. ccguntur@preethi.in
- Hyderabad** - Ph:040-23063848. ccckukatpalli@preethi.in
- Hyderabad** - Ph:040-27661588. ccchderabad@preethi.in
- Saroor nagar** - Ph:040-24044858. ccchydsm@preethi.in
- Kadappa** - Ph:08562-246552. ccckadappa@preethi.in
- Karim Nagar** - Ph:0878-2245211. ccckarimnagar@preethi.in
- Khammam** - Ph:08742-228970. ccckhammam@preethi.in
- Kurnool** - Ph:08518-222358. ccckurnool@preethi.in
- Mancherial** - Ph:08736-254222. ccmancherial@preethi.in
- Nellore** - Ph:0861-2321998. ccnellore@preethi.in
- Nizamabad** - Ph:08462-229526. ccnizamabad@preethi.in
- Ongole** - Ph:08592-284914. cccongole@preethi.in
- Rajahmundry** - Ph:0883-2441321. ccrajamundry@preethi.in
- Secunderabad** - Ph:040-27819516. ccsecunderabad@preethi.in
- Srikakulam** - Ph:08942-222448. ccscrikakulam@preethi.in
- Tirupathi** - Ph:0877-2258966.
- Alapuzha** - Ph:0477-2230896. ccupaluzha@preethi.in
- Attingal** - Ph: 0470-2624165. ccattngal@preethi.in
- Trivandrum** - Ph: 0471-2408461. ccbalaramapuram@preethi.in
- Calicut** - Ph:0495-2724080. ccocalicut@preethi.in
- Chenganacherry** - Ph:0481-2424383. ccchanga@preethi.in
- Cochin** - Ph:0484-2370781. ccceamakulam@preethi.in
- Kanhangad** - Ph:0467-2200799. ccckanhangad@preethi.in
- Kannur** - Ph:0497-2765948. ccckannur@preethi.in
- Kollam** - Ph:0474-2708800. ccckollam@preethi.in
- Kottayam** - Ph:0481-2584793. ccckottayam@preethi.in
- Malappuram** - Ph:0483-2735948. ccmmalappuram@preethi.in
- Palakkad** - Ph:0491-2536016. ccopalakkad@preethi.in
- Pathanamthitta** - Ph:0468-2325605. ccpathanamthitta@preethi.in
- Perambavoor** - Ph:0484-2595723. ccperumbavoor@preethi.in
- Thalassery** - Ph:0490-2341761. cccthalassery@preethi.in
- Thodupuzha** - Ph:0486-2220292. cccthodupuzha@preethi.in
- Trissur** - Ph:0487-2380919. ccctrissur@preethi.in
- Tripunithra** - Ph:0484-2778728. ccctripunithra@preethi.in
- Trivandrum** - Ph:0471-2341216. ccctrivandrum@preethi.in

### KERALA

- Alapuzha** - Ph:0477-2230896. ccupaluzha@preethi.in
- Attingal** - Ph: 0470-2624165. ccattngal@preethi.in
- Trivandrum** - Ph: 0471-2408461. ccbalaramapuram@preethi.in
- Calicut** - Ph:0495-2724080. ccocalicut@preethi.in
- Chenganacherry** - Ph:0481-2424383. ccchanga@preethi.in
- Cochin** - Ph:0484-2370781. ccceamakulam@preethi.in
- Kanhangad** - Ph:0467-2200799. ccckanhangad@preethi.in
- Kannur** - Ph:0497-2765948. ccckannur@preethi.in
- Kollam** - Ph:0474-2708800. ccckollam@preethi.in
- Kottayam** - Ph:0481-2584793. ccckottayam@preethi.in
- Malappuram** - Ph:0483-2735948. ccmmalappuram@preethi.in
- Palakkad** - Ph:0491-2536016. ccopalakkad@preethi.in
- Pathanamthitta** - Ph:0468-2325605. ccpathanamthitta@preethi.in
- Perambavoor** - Ph:0484-2595723. ccperumbavoor@preethi.in
- Thalassery** - Ph:0490-2341761. cccthalassery@preethi.in
- Thodupuzha** - Ph:0486-2220292. cccthodupuzha@preethi.in
- Trissur** - Ph:0487-2380919. ccctrissur@preethi.in
- Tripunithra** - Ph:0484-2778728. ccctripunithra@preethi.in
- Trivandrum** - Ph:0471-2341216. ccctrivandrum@preethi.in

### MAHARASTRA

- Mumbai** - Ph:09168697502. ccmmumbai@preethi.in
- Pune** - Ph:09168697490. ccppune@preethi.in
- Nagpur** - Ph:09168697499. ccnagpur@preethi.in
- Kolapur** - Ph:09168697491. ccckolapur@preethi.in
- Nashik** - Ph:09168697495. ccnashik@preethi.in
- ODISHA**
- Bhubaneswar** - Ph: 0674-2597356. ccchubaneswar@preethi.in
- GUJARAT**
- Ahmadabad** - Ph: 079-27544037. ccchahmadabad@preethi.in

|                  |                                 |   |   |
|------------------|---------------------------------|---|---|
| Customer Support | One number for all your queries | One address for all your communication    | Philips Domestic Appliances India Ltd.<br>Futura Tech Park, Q4, 4th Floor, Block-B, #334, Rajiv Gandhi Salai, (OMR), Sholinganallur, Chennai-600119. INDIA. Ph:+91-44-24501042, +91-44-24501044. Email: info@preethi.in   Web: www.preethi.in |
|                  | 99400 00005                     | care@preethi.in                           |   |
| Social Media     | Like Us:                        | www.facebook.com/PreethiKitchenAppliances |   |
|                  | Follow Us:                      | www.twitter.com/PreethiIndia              |   |
|                  | Subscribe Us:                   | www.youtube.com/user/PreethiIndia         |   |

**Preethi**  
CROWN  
Plus



Reliable performance at its best

5 YEAR MOTOR WARRANTY  
2 YEAR PRODUCT GUARANTEE  
LIFELONG FREE SERVICE

\*Applicable only on products purchased in India. Charges apply for replacement of spares/accessories. For detailed terms & conditions please refer the Guarantee Card. Images are for illustrative purposes only.

## INSTRUCTION MANUAL


### Technical Specifications:

|                                      |   |
|--------------------------------------|---|
| Model Name & Number                  | : Crown Plus - MG258  |
| Voltage                              | : 230V ~ 50 Hz.   |
| Power Consumption                    | : 600 Watt  |
| Insulation                           | : Class F   |
| Protection                           | : Class II  |
| Protection against dust and moisture | : Ordinary  |
| Protection against ingress of water  | : IPX0  |
| Rating                               | : Ordinary total rated ON time 30 minutes (max), Continuous ON for 5 minutes (max.) and Off for 2 minutes (min.) Rest time 45 minutes |
| Motor                                | : Universal 600 Watt high power motor. No load speed 18,000 RPM (approx.) With load speed 10,500 RPM (approx.)                        |
| Material of Body                     | : ABS   |
| Material of Jars                     | : Stainless steel & Transparent Plastic   |
| Blade Assemblies                     | : Stainless steel, machine ground and polished.   |
| Speed Controls                       | : Rotary switch with 3 speed and incher.  |
| Flex Cord                            | : PVC insulated flexicord with plugtop  |
| Country of Origin                    | : INDIA   |

In pursuance with our policy of continuous product improvement, specifications are subject to change without notice.

|                               |                                 |
|-------------------------------|---------------------------------|
| Gross Weight                  | 4.5 Kgs. (approx)               |
| Size of Carton L x B x H (mm) | 455mm (L)x 245mm (W)x 325mm (H) |
| Guarantee                     | 2 Years on the Mixie            |
| Warranty                      | 5 Years on the Motor            |

## Know your Preethi Crown Plus



1. Base unit with 600 W motor
2. Over Load Protector
3. Switch knob
4. 1.5 Litre Super Extractor Jar with fixed blade
5. 1.2 Litre Wet Grinding Jar with fixed blade
6. 0.7 Litre Dry Grinding Jar with fixed blade
7. 0.3 Litre Chutney Jar with fixed blade

### Note:

- Jar Placing** : Place the Jar on the Top Cap, Ensuring that the locks fit properly in the Jar locking Grooves of the Top Cap.
- Dome** : Ensure that the Dome Gasket is properly fitted and hold Dome gently while operating
- Speed Control** : Turn Rotary Switch clockwise for speed 1,2 or 3 as desired. Inching-Turn Rotary Switch anti-clockwise for a few seconds and release or momentary operation. *(Inching is especially useful for wet grinding of chutneys, crushing ice, etc.,)*

### Standard Recipes

| No. | Jar Capacity  | Recipe              | Quantity   | Speed   | Time    |
|-----|---|---------------------|--|---------|---------|
| 1.  | Big Jar<br>1.25 Litre                                 | Urad Dal            | 125g + 338ml water soaked for 6-8hrs. Add 50ml water | P,1,2,3 | 5.0 min |
|     |   | Rice                | 250g + 282ml water soaked for 6-8hrs. Add 50ml water | P,1,2,3 | 5.0 min |
| 2.  | Medium Jar<br>0.75 Litre                              | Garam Masala        | 150g of assorted spices roasted and cooled           | P,1,2,3 | 2.0 min |
|     |   | Wet Masala          | 150g onion + 100g tomato                             | P,1,2,3 | 2.0 min |
| 3.  | Small Jar<br>0.33 Litre                               | Ginger garlic paste | 50g ginger + 50g garlic                              | P,1,2,3 | 1.5 min |
| 4.  | <b>Appliance not suitable for Whisking Egg Whites</b> |                     |  |         |         |

| Jar                 | Capacity   | Wet Max. Rated Capacity | Dry Max. Rated Capacity |
|---------------------|------------|-------------------------|-------------------------|
| Super Extractor Jar | 1.50 Litre | 0.60 Litre              | NA                      |

\*Minimum capacity for all the above at-least up to blade level

## How to use Preethi Crown Plus

**Wash before 1st use:** Take some warm soapy water in the jar so that blade is completely immersed and close it with lid. Fix the jar in the main unit & run it for a minute. Then pour out the soapy water & fill it with clean water and repeat this process till any trace of soap is removed.

PREETHI is provided with PVC insulated flexicord with plugtop. Plug the power cord to a 230V~50Hz supply only. If the supply cord is damaged, it must be replaced by the manufacturer or its authorised service agent only in order to avoid a hazard.

### Grinding Instructions:

**ROASTED CEREALS, RAW RICE, DAL, CHILLI POWDER, GARAM MASALA, DHANIYA JEERA POWDER, CURRY LEAF POWDER, COFFEE POWDER, SAMBAR/ RASAM POWDER...**

- ▶ Ensure Blade, Jar, Lid and ingredients are totally dry.
- ▶ Run on Speed 3.
- ▶ If you need finer powder, wait for 1 minute and grind again for 1 to 2 minutes.



**IDLI, DOSA, UTHAPPAM, APPAM, PESARATTU, VADAI...**

- ▶ Soak Rice/Dal for 4 to 5 hours or as required.
- ▶ Drain water from ingredients.
- ▶ Run on Speed 3 adding water gradually when required.
- ▶ If Material sticks to the sides of the Jar, stop and stir using Stirrer, run again.
- ▶ Ensure free circulation by adding enough water.
- ▶ Do not allow batter to get heated up.
- ▶ Do not add too much water, where thick paste is required.
- ▶ Grind twice if quantity is more.



**Note:** While wet grinding tough batter, air bubbles may enter the paste. This will result in the blade rotating freely and an increase in noise. If so, stop, stir the paste and restart.

**COCONUT, TOMATO, ONION, CORIANDER, MINT CHUTNEY**

- ▶ Inch 5 to 7 times to powder ingredients.
- ▶ Then add water as required.
- ▶ Grind on Speed 3




**VEGETABLE, FRUIT JUICES, LASSI, COCONUT MILK, TAMARIND EXTRACTION MILK SHAKES (Super Extractor)**

- ▶ The Juicer Blade and Filter should be used only for extraction and juicing.

### Overload Protector

If the Mixie stops while in usage due to operation of the Overload Protector, then:

1. First switch OFF the Mixie & unplug the power cord.
2. Remove some material which is being ground from the Jar decrease the load.
3. Wait for 3 - 5 minutes.
4. Lift the Unit and press the KNOB projecting out of Bottom plate.
5. Re-start the Mixie.



### Cleaning the Mixer Grinder

1. Clean Mixer Grinder with a damp cloth and wipe dry.
2. Do not use abrasives or water for cleaning.

### Cleaning the Stainless Steel Jars and Blades

1. Fill in ½ litre of water and a teaspoon of any mild cleaning powder.
2. Run the Mixie on Speed 1 for 30 seconds, leaving the Blade fixed to the Spindle of the Stainless Steel Jar. 3. Rinse and dry.
4. Always store Jars in inverted position to allow water to drain off.



1. When operating the Grinder for the first time or after long storage or when the Mixie has been shifted over a long distance, rotate the Motor Shaft by hand through the Motor Coupler, until the Motor Shaft rotates freely.
2. Unplug from power socket before fixing, removing attachments and also while cleaning or when not in use.
3. **Ensure that the locks of the Stainless Steel Jar Housing are properly seated in the locking grooves provided inside the Top Cap and Dome is fixed properly on the Jar before starting the Mixie.**
4. **Ensure Blade is fitted properly before running.**
5. Check if the voltage indicated on the base of the appliance, corresponds to the local electrical main voltage before connecting the appliance.
6. Always unplug the appliance after use.
7. In Super Extractor - When using filter always use adaptor



1. Do not touch moving parts, while operating Mixie.
2. Do not overload Mixie. When hot air emanates from the opening on the Top Cap, switch off the Mixie and wait for 3-5 minutes, before re-starting.
3. Do not remove Dome and add solid ingredients, when the Motor is running.
4. Do not operate with damaged Power Cord.
5. Do not tamper or attempt to repair Grinder on your own, Contact nearest Preethi Customer Care Centre.
6. Do not grind hot ingredients in the Grinder.
7. Do not run the Grinder without Top Dome /Lid fixed on the Jar.
8. Do not place the Jar on Top cap of Base unit when the Switch is in "ON" Condition.
9. Never put your hand inside the Jar, without switching OFF the power supply.
10. Do not place the appliances on an unstable surface.
11. Do not move the appliances during operation.
12. This appliance should not be used 2000metres above the sea level.
13. Children should be supervised to ensure that they do not play with the appliance.
14. Cleaning and user maintenance shall not be used by children. Keep the appliance and its cord out of reach of children.
15. Do not use the appliance when the mains cord, the plug or other components are damaged. Only the company or service center authorized by Preethi must replace it.
16. Never touch food in the jar by hand. Always use a spatula.
17. Never leave the appliance running unattended.
18. Keep the appliance away from the source of heat like gas or electric stove.
19. Do not run the appliance with the jar empty.
20. Never load the jar with ingredients beyond the maximum level (See "Guide to Function" on same page for standard recipes details).
21. Do not use any attachment other than those provided or recommended by the manufacturer. It may cause hazards.
22. In Super Extractor- DO not run without locking Filter properly.
23. In Super Extractor: Do not pierce filter with sharp objects while cleaning.

**Caution:** This appliance is not intended for use by persons (Including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.